




# Assembly Instructions

Please keep for future reference

NORFOLK TWO TONE TALL DISPLAY UNIT

CAT NO: JS562



## Dimensions

Width: 95.0cm  
Depth: 33.0cm  
Height: 117.3cm

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **JDW Customer Helpline: 0871 231 2000**

## Safety and Care Advice

**Important** - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on next pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.
- Warning : Do not over tighten the handle screw that way break the mirror.



### Care and Maintenance

- Please clean using cloth with glass cleaner, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**If you have damaged or missing components, call the JD Williams Customer Helpline on 0871 231 2000**

**If you are unhappy with the product and wish to return it, please follow the retailer's returns procedure.**



## Warning

**Important** - In order to help prevent overturning, this product must be used with the wall anti-tip strap/device provided.

To help prevent product toppling over please follow the below steps :


- Use the anti-tip strap/device provided.
- Do not allow children to climb or hang on the furniture.
- Do not open more than one drawer at a time.
- Do not place heavy items in the top drawer.
- Do not place heavy items on the top of furniture, unless the furniture has been designated for this purpose.

Please note that the only anti-tip strap/devices and screw are provided, you will need to provide wall plugs and screws applicable for your wall type.


**PLEASE DO NOT REMOVE THE PERMANENT SAFETY LABEL FROM YOUR FURNITURE !**

### Permanent Label Assembly Location

1. Wardrobe/Cabinet without Drawer :  
Inside back panel visible/below the shelf.



2. Chest of Drawer/sideboard/Unit with Drawer :  
Top drawer on the inside side of drawer wrap.






*Note: For uncommon furniture design, the location of safety permanent label may differ.*

# Components - Fixings


Please check that you have all the components listed below before constructing your items.

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


\*Hardware packed separately according to the code.

(a)	CSK M4x20mm	(b)	Safety Bracket	(c)	Safety Strap	(d)	Support Bracket
							
	12 units		4 units		2 units		2 units

## Tools Required




Ruler - Use this to measure your screws (mm)








# Assembly Instructions

## Step 1










CAUTION HEAVY  
LIFT WITH CARE !

	
<b>a x 8</b>	<b>d x 2</b>



## Step 2



		
<b>a x 4</b>	<b>b x 4</b>	<b>c x 2</b>

**Step 3**

