



- To reset the Filter Service Indicator, press and hold the Filter Reset Button (  ) for 3 seconds while the unit is operating (in any speed). The light will flash 3 times and then go out. The filter check timer is now reset.

#### POWER CORD PLUG

If the plug is not suitable for the socket outlets in your home, it can be removed and replaced by a plug of the correct type.

#### Installation of a plug Applicable to U.K. and Ireland.



**NOTE:** If the terminals in the plug are not marked or if you are unsure or in doubt about the installation of the plug please contact a qualified electrician.

If a 13A (3-pin) plug is fitted, it must be an ASTA approved plug, conforming to BS1363 standard.

Replacement 5A fuses must be BS1 or ASTA BS1362 approved.


This product is fitted with a 13A plug complying to BS1363. If this plug is unsuitable or needs to be replaced, please note the following:

The wires in the mains lead are coloured as such:  
 BROWN - LIVE  
 BLUE - NEUTRAL

Please note that the colour of these mains wires may not correspond with the colour markings that identify the terminals in your plug. Please proceed as follows:

The BROWN coloured Live wire must be connected to the terminal, which is marked with the letter "L" or is coloured RED.

The BLUE coloured Neutral wire must be connected to the terminal, which is marked with the letter "N" or is coloured BLACK.

DO NOT CONNECT either of these mains wires to the earth terminal in the plug. The earth terminal plug is marked with the letter "E", or with the earth symbol , or coloured GREEN, or GREEN and YELLOW.

#### GUARANTEE

Please keep your receipt as this will be required for any claims under this guarantee.

This appliance is guaranteed for 2 years after your purchase as described in this document.

During this guaranteed period, if in the unlikely event the appliance no longer functions due to a design or manufacturing fault, please take it back to the place of purchase, with your till receipt and a copy of this guarantee.

The rights and benefits under this guarantee are additional to your statutory rights, which are not affected by this guarantee. Only Jarden Consumer Solutions (Europe) Limited ("JCS (Europe)") has the right to change these terms.

JCS (Europe) undertakes within the guarantee period to repair or replace the appliance, or any part of appliance found to be not working properly free of charge provided that:

- you promptly notify the place of purchase or JCS (Europe) of the problem; and
- the appliance has not been altered in any way or subjected to damage, misuse, abuse, repair or alteration by a person other than a person authorised by JCS (Europe).

Faults that occur through, improper use, damage, abuse, use with incorrect voltage, acts of nature, events beyond the control of JCS (Europe), repair or alteration by a person other than a person authorised by JCS (Europe) or failure to follow instructions for use are not covered by this guarantee. Additionally, normal wear and tear, including, but not limited to, minor discoloration and scratches are not covered by this guarantee.

The rights under this guarantee shall only apply to the original purchaser and shall not extend to commercial or communal use.

If your appliance includes a country-specific guarantee or warranty insert please refer to the terms and conditions of such guarantee or warranty in place of this guarantee or contact your local authorized dealer for more information.

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



Jarden Consumer Solutions (Europe) Limited  
 Middleton Road  
 Royton  
 OL2 5LN  
 UK



**Jarden Consumer Solutions (Europe) Limited**  
**Royton, Oldham OL2 5LN**  
**England**

**Fax: +44 (0)20 8947 8272**  
**Email: [enquiriesEurope@jardencs.com](mailto:enquiriesEurope@jardencs.com)**  
**UK - Filter Sales Order Line - 0870 759 9000**  
**Website address: [www.bionaire.com](http://www.bionaire.com)**  
**UK - Free phone Customer Service Helpline – 0800 052 3615**



© 2013 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. Distributed by Jarden Consumer Solutions (Europe) Limited, Middleton Road, Royton OL2 5LN, United Kingdom.  
 Printed in PRC

GCDS-BIO25982-PH

P.N. 172956  
 BAP600-060\_12EM1



pure indoor living




**AIR PURIFIER**  
 with HEPA-type  
 Permanent Filter

MODEL: BAP600

**INSTRUCTION MANUAL**

Figure 1

# BAP600



## U.K. AND IRELAND

### PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS.

With proper care and use, this air purifier will give you fresh, clean air for many years.

**NOTE:** Before reading these instructions, please view the corresponding illustrations.

### DESCRIPTIONS (See Figure 1)

- A. Filtered Air Outlet
- B. Air Purifier Housing
- C. Night Light
- D. Base Air Inlet Grill
- E. Power Button/Light
- F. Ioniser Button/Light
- G. Night Light Button
- H. Filter Reset Button/Filter Service Indicator Light
- I. Speed Control Buttons (3-2-1)/Lights
- J. Permanent HEPA-type Filter (not shown)

### SAFETY PRECAUTION

Carefully read and retain all instructions before using the air purifier.

**This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.**

**Cleaning and user maintenance shall not be made by children without supervision.**

**If the supply cord or plug is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.**

- To avoid fire or shock hazard, check that the voltage on the product corresponds to your electricity supply and plug directly into an electrical outlet.
- To avoid fire hazard, never put the cord under rugs, or near any heat source.
- Carefully discard any plastic wrapping that was used for the packaging.

- Do not use the air purifier outside.
- Do not place the unit near any heat source or in direct sunlight.
- Always unplug the air purifier before removing the grill, changing the filters, cleaning the air purifier or whenever it is not in use.
- Do not use in or around water or any other liquids.
- Do not attempt to wash the unit under running water.
- Use appliance only for intended household use as described in this manual.

- Ensure that all air openings are not restricted or covered in any way.
- Do not place anything on top of the unit.
- Never insert any object into any openings.
- Do not use the air purifier if any part is missing or damaged in any way.
- Do not attempt to repair or adjust any mechanical functions of this unit. If the unit becomes damaged return to the place of purchase or phone the helpline number on the back of this leaflet.

- The air purifier contains no user serviceable parts and should the product suffer damage or breakdown, it must be returned to the manufacturer or its service agent.
- Should the air purifier stop working, first check the fuse in the plug or fuse/circuit breaker at the distribution board is operating, before contacting the manufacturer or service agent.
- Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.
- **CAUTION:** To prevent the risk of electric shock, remove the cord plug from the outlet before opening the appliance. To prevent the risk of fire, inspect and clean the appliance regularly as noted in this manual.

### HOW THE AIR PURIFIER WORKS

Your Bionaire® air purifier features a Permanent HEPA-type filter that removes up to 99% of pollen, pet dander, dust and mould spores as small as 2 microns from the air passing through the filter.

- Permanent filters can be vacuumed every few months for easy cleaning.
- Optional ioniser naturally improves performance and helps freshen the air.
- Slim tower design allows placement in almost any area of the room.

### PRODUCT FEATURES

#### Ioniser

This appliance has an optional ioniser feature which, when turned on, releases negative ions into outgoing filtered air to help the air purification process.

#### What Are Ions?

Ions are tiny particles that carry a positive or negative

charge. They exist naturally around us: in the air, water, and ground. Both positive and negative ions are colourless, odourless, and completely harmless.

#### How Does The Ioniser Work?

Negative ions help air purification by attaching themselves to very small airborne particles in the room. These particles take on a negative charge and may join with positively charged particles such as dust, pollen, smoke, and pet dander to form larger particles. The larger particles are then more easily captured by the filter system.

#### Important Notes:

Your ioniser may produce an occasional popping or cracking sound. This is normal and occurs when a small buildup of ions is discharged.

After extended use, you may notice dust around the grills or front panel.

- This is caused by negative ions exiting the air outlet, evidence of the ioniser's air cleaning effectiveness.
- You can remove the dust with a soft brush or clean, damp cloth.

Larger particles may be attracted to positively charged surfaces throughout the home, like walls or floors.

- This may occur more frequently when the filter is nearing the end of its useful product life and unable to capture as many charged particles.
- Excessive amounts of pet dander, dust, or smoke may decrease the life expectancy of the filter(s) and interfere with the ionisation process.

To help prevent particles from attracting to surfaces throughout your home:

- You may want to run the ioniser less often.
- Check the condition of the filter(s) more frequently.

**CAUTION:** The ioniser in this appliance produces less ozone than the UL established limits of 50ppb (tested and listed by the Underwriters Laboratories, Inc.). However, in high concentrations, ozone can be harmful to birds and small pets. To prevent ozone buildup, we suggest using the ioniser in well ventilated areas with the fan on.

**IMPORTANT:** Always clean the filter at the recommended intervals (See CLEANING THE PERMANENT HEPA-TYPE FILTER). Using the ioniser with dirty filters may result in dirty particles exiting the air purifier and attracting to walls, carpets, furniture, or other household objects. These dirty particles may prove difficult to remove.

#### HEPA-TYPE FILTER

The filter allows easy maintenance and eliminates the hassle of filter replacement. HEPA-type (High Efficiency Particulate Air) filters are designed to remove up to 99% of airborne pollutants, at 2 microns or larger, from the air that passes through them. These include tobacco smoke, household dust, pet dander and pollen.

#### Filter Indicator

The filter indicator light eliminates guesswork by letting you know when it is time to clean the filters.

#### Night Light

The Night Light offers an optimal illumination for night time use. Press the Night Light button to activate and deactivate the night light.

#### High, Medium, and Low Speed Settings

For optimum air filtration, operate your Bionaire® Air Purifier continuously on the 3 setting. Its rugged motor has been designed to give many years of use. For quieter operation (such as in a bedroom), select 1 setting.

#### PRE-OPERATING INSTRUCTIONS

1. Carefully unpack your air purifier.
2. Select a firm, level surface with no obstructions to the air inlets or outlets.
3. If the filter is covered by a bag when shipped, remove plastic bag before use and place filters into unit (See REINSTALLING THE FILTER AFTER CLEANING).

#### OPERATING INSTRUCTIONS

##### IMPORTANT:

- Remove all plastic bags from filters before use.
- DO NOT POINT THE FILTERED AIR OUTLET TOWARDS A WALL.
- DO NOT USE THE IONISER FOR LONG PERIODS OF TIME AS THIS CAN CAUSE BLACKENING OF WALLS IF THE FILTERS ARE NOT CLEANED REGULARLY.

##### To operate your air purifier:

1. Plug into an electrical outlet.
2. Press the power button (D). The air purifier will turn onto HIGH, the power light and the High (3) speed indicator light will illuminate letting you know the power is on and running at High setting. To turn the air purifier off at any time, press the power button and all indicator lights will go off.
3. You can then select the desired speed setting. This air purifier has three speed settings. You can select from HIGH (3), MEDIUM (2), or LOW (1) by pressing the desired operating speed control button on the control panel. The corresponding indicator light will illuminate to indicate which setting is selected.
4. To release negative ions into the filtered air, press the ioniser button (X) and the indicator light will illuminate.
5. To activate the Night Light at any speed setting, press the night light button (V) to illuminate. Press the button again, the night light will go off.

#### CLEANING AND MAINTENANCE

1. Turn the air purifier off and unplug it before cleaning.
2. The outside of the air purifier can be cleaned with a soft, clean dampened cloth.

3. The base air inlet grill can be removed and washed in warm soapy water (not dishwasher safe). Dry before replacing in the unit.
4. The filtered air outlet can be cleaned of dust with a small, soft brush.
5. If you wish to clean the inside filter chamber, please only use a dry, soft cloth to wipe it down.

**WARNING:** Do not allow moisture to come in contact with the main housing of the air purifier.

#### Cleaning The Permanent HEPA-type Filter

##### IMPORTANT:


- If the filter is enclosed in plastic bag, remove it before use.

**NOTE:** Every few weeks, check the condition of filter. Filter life will vary, depending on air quality and usage. Under normal conditions of continuous use, the HEPA-type filter will operate efficiently for 3-4 months, but we recommend regular cleaning for optimal performance.

After approximately 4 months of operation, the Filter Service Indicator will illuminate (yellow LED) to alert you to clean the filter before further use.


##### To remove the filter for cleaning:

1. Turn off and unplug the air purifier.
2. To open and release the base air inlet grill from the base, use the handle on the base grill and turn it counter-clockwise until the Unlock icon (U) is aligned with the indicator mark below the power cord outlet on the rear side of the air purifier housing (see Figure 2).



3. Take out the permanent HEPA-type filter from the unit, check the condition of the filter, and remove for cleaning if dirty.

4. Using your vacuum cleaner, run the brush attachment along both sides of the filter and clean between the pleated layers (see Figure 3).



**IMPORTANT: Do not use water, household purifiers or detergents to clean the filter.**

**The filter may appear discolored even after vacuuming. This is normal and does not affect performance in any way—a new filter is not necessary.**

**If the filter becomes damaged during cleaning, call 0870 759 9000 (UK number) to order replacements.**

#### Reinstalling the Filter and Resetting the Filter Indicator Light

##### To reinstall the permanent filter after cleaning:

1. Install the cleaned filter into the air purifier housing then replace the base air inlet grill. To replace the base air inlet grill, turn it clockwise using the base grill handle until the Lock icon (L) on the base is aligned with the indicator mark below the power cord outlet on the rear side of the air purifier housing. Ensure the base air inlet grill is locked securely in place (see Figure 4).

