
## 1 Door Storage Cabinet

Assembly Instructions - Please keep for future reference

011 xx 9435



#### **Dimensions**

Width - 42.0cm

Depth - 35.0cm

Height - 79.0cm



### Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 01709 534123** Please turn to back page for important information when contacting Customer Helpline.



## Safety and Care Advice

### Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws.

as this could damage the unit. Only use hand screwdrivers.

- Do Not dispose of packaging until assembly complete.
- Dispose of all packaging carefully and responsibly when assembly complete.

#### Care and maintenance

- To protect the furniture, position the furniture out of direct sunlight and away from direct heat sources such as radiators and fires.
- Do not place the furniture in excessively dry and humid conditions.
- From time to time check that there are no loose screws on this unit.
- Always lift furniture when moving it (do not drag) otherwise the joints may be damaged.

- Do not place hot or cold objects on the surface, always use protective mats to avoid marking the furniture.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.
- Clean spills up immediately
- Dust surfaces with a soft, dry, lint free cloth.


- More stubborn marks can be removed using a damp (not wet) cloth. Wipe the surface dry immediately using a soft lint free cloth.
- Do not use detergents, abrasive cleaning products or cleaning products that contain ammonia, solvents or silicone as these may damage the surface finish.


## Components - Panels

### Please check you have all the panels listed below



Important - Thick lines — indicate finished edges






1491


Shelf x 3 (39x34.8cm)





1493

Door Panel (36.6x38.4cm)



1492

End Panel x 2 (79x35cm)

1494

Back Panel (78.5x41.6cm)



## Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 01709 534123** Please turn to back page for important information when contacting Customer Helpline.

### Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly, In some cases more fittings may be supplied than are required.

	Screw x 12 Code 690001075	B Spiller	Screw x 4 Code 690001008	Θ		18mm bolt x 2 Code 700002021
	12mm Screw x 2 Code 690001099	<b>3</b>	Panel pin x 24 Code 760001012	G		Fully cranked 26mm hinge x 2 Code 652001120
<b>(1)</b>	Hingeplate x 2 Code 653006000	0	Handle x 1 Code 643003506	0		Panel pin guide x 1 Code 684004501
<b>6</b>	L Bracket x 1 Code 760001901		Cover cap x 12	8	$\bigcirc$	Door Stopper x 1 Code 680362030

### Tools required



Cross headed screwdriver (medium & large )



Tape Measure



Eye protection (when using a hammer)



Small Hammer




Bradawl

## Ruler - Use this ruler to help correctly identify the screws

70 0 mm 10 20 50 60 80 100 110 120 130 140 170 30 40 90 150 160

# **Exploded View**



## Step 1

**Attach hinges and** handles to the doors



a: Insert hinges G into holes, ensure the hinge is straight (90 degree angle).









1493













**b:** Before securing the hinges **G**, we recommend you pre - mark the doors using a bradawl.









C: Secure hinges G to doors using screws **B**.








d: Secure handle Oto doors using bolts **C** 






### Step 2

Fitting door stop on the shelf panel.


Insert plastic door stop N into one of the shelf panels 1491 as shown.



### Step 3

Secure shelf panels to end panel.


Locate screws A through holes in end panel 1492 and screw into holes in shelf panel 1491



### Step 4

Secure shelf panels to end panel.

Locate screws (A) through holes in end panel (1492) and screw into holes in shelf panel (1491)



## Step 5

## Squaring up the unit. IMPORTANT!



Ensure a tape measure is used to square unit up.


Before securing the back it is necessary to square up the unit.


You can do this by measuring between XX - XX and YY - YY ensuring these are the same (DIAG 1).

If they are not (DIAG 2) Apply slight pressure as indicated (DIAG 3) until they are the same.



Measure to external corners





## Step 6


#### Secure back panel

Use the panel pin guide when locating the panel pins. This will hold the panel pins vertical and ensure the correct distance from the edge.










### Step 7


### Fitting hinge plates to the end panel.

Attach hinge plates **(H)** to the end panel 1492 as shown

Please note that the doors can be hung at either side of the unit.







### Step 8


#### **Hanging doors**


a: With help, slot door hinges onto hinge plates. Ensure screw on hinge slides into the slot on hingeplate.

See Diagrams 1, 2 and 3.

**b:** Tighten screw shown to lock hinges in position.

See 'Hinge adjustment' page if the doors need adjusting.








Diagram 1




Diagram 2





Diagram 3



## Step 9

### Hinge adjustment

**a:** To move doors up or down: loosen screws shown and move doors to suit.

Re-tighten screws.


**b:** To move doors in or out: loosen screw shown and move doors to suit.


Re-tighten screws.

**C:** To move doors left or right: loosen or tighten screw as shown.


Be careful not to fully unscrew.










В





C





x12

### Step 10

#### Fixing to wall

We recommend that this unit is fixed to a suitable wall to prevent possible overbalancing. We have included a fixing bracket for this. No fixing screws are provided as they will need to suit the wall type, and the length of screw will depend on the distance from the back of the unit to the wall. Please ensure fixings used are appropriate to your wall type. Locate the bracket to the top panel or to the end panel as close to top as possible. We do not specify exact location for the bracket, this is left to the customer's discretion.

With help move the unit into position.



Warning: 2 people required. Lift with care.



Warning:

Please take care when drilling into the wall, avoiding any pipes and wires. Wear safety goggles when drilling. The use of residual current device (RCD) is recommended when working with tools. If in doubt consult a qualified person.

# Use the cover caps to conseal exposed fittings.

Using the 12 cover caps
provided, conceal the exposed screws by placing these caps over them.



## **WARNING**


IN ORDER TO PREVENT OVERTURNING
THIS PRODUCT MUST BE USED WITH
THE WALL ATTACHMENT DEVICE
PROVIDED

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over:


- Use the wall attachment device provided.
- Never allow children to climb or hang on drawers, doors or shelves.
- Place heaviest items in the lower drawers or shelves
- Unless specifically designed to accomodate, do not set TV's or other heavy objects on top of this product.
- Never open more than one drawer at a time.

An attachment device is provided with your product. However you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified trades person.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



## Congratulations! Your unit is complete.



## Important Information

If you need help or have damaged or missing parts, call the Customer Helpline:

01709 534123 8am - 4.30pm (Monday to Thursday) 8am - 2.30pm (Fridays)

(by contacting the customer service line your statutory rights are not affected)

Please have the following information to hand:

- >> Unit Description
- >> Product Code
- >> Product Colour
- >> Place of Purchase
- >> Catalogue Ref. No.
- >> Item Code
- >> Assembly Instructions

We do have an answer machine should you contact us out of office hours, so in addition to the above information could you leave your name, address, daytime telephone number and the nature of your call on the answerphone. All calls will be actioned asap.

You can also e-mail your requests to us at:

### customer.helpdesk@addspacefl.co.uk

Alternatively, you can write to us at: Customer Service Department, Addspace Furniture Limited, Braithwell Way, Hellaby Industrial Estate, Hellaby, Rotherham, South Yorkshire, S66 8QY.