


HALO WIDE TV UNIT

Assembly Instructions - Please keep for future reference

Cat No

XK026



Dimensions	No. people	Assembly Time
Width: 147.8cm Depth: 41.4cm Height: 39.9cm	ÅÅ	45 Minutes (approx.)


Important - Please read these instructions fully before starting assembly



Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 4 and 5.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.

We do not recommend the use of power drill/drivers for



hand screwdrivers.

 Dispose of all packaging carefully and responsibly.


Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

If you have damaged or missing components, call the JD Williams Costumer Helpline on 0871 231 2000

If you are unhappy with the product and wish to return it, please follow the retailer's returns procedure.

Exploded View



Components - Panels

Please check that you have all the components listed below before constructing your items.

Part No	Description	Qty				
Α	Top Panel					
В	Bottom Panel					
С	Side Panel - L					
D	Side Panel - R					
E	Divider panel - L					
F	Divider panel - R					
G	Adjustable Shelf	1				
Н	Door	2				
I	Led Panel Support					
J	Front Panel					
K	Panel Support					
L	Glass LED Support					
M	Front Bottom Support	1				
N	Rear Bottom Support	1				
0	Middle Bottom Support	2				
Р	Midle Back Panel	1				
Q	Back Panel - L					
R	Back Panel - R					

Components - Fixings

Please check that you have all the components listed below before constructing your items.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

*Hardware packed separately according to the code.

(A)	Minifix Cam	(B)	Minifix Bolt	(C)	Minifix Cover	(D)	Dowel M8 x 32mm
	S)				6		
	35 units	1	35 units		31 units		24 units
(E)	Screw M4 x 10mm	(F)	Screw M10 x 33.5mm	(G)	Screw M4 x 19mm	(H)	Backply Stopper
	Omm				()mmmm>		
	8 units	1	10 units		20 units		18 units
(I)	Backply clip	(J)	Shelf Support	(K)	Screw M4 x 12mm	(L)	Screw M4 x 15mm
	2 units		4 units		4 units		2 units
(M)	Ring Plastic	(N)	Door Buffer	(O)	Hinge	(P)	Glass Support
				, ,	Omm		
	2 units		4 units		4 units		4 units
(Q)	Adaptor	(R)	Corner Bracket	(S)	Cable Holder		
	1 units]	2 units		2 units		

Tools Required



Ruler - Use this to measure your screws (mm)

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

