


New England 4 Drawer Unit

Assembly Instructions - Please keep for future reference

QN856



Dimensions

Width - 19cm
Depth - 25cm
Height - 65cm

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3..
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the using. Only use hand screwdrivers

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightend properly.


Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


Please check you have all the panels listed below




1 Top Panel x1
19(w)cm x 25(d)cm




2 Left side Panel x1
23.8(d)cm x 63.8(h)cm




3 Right side Panel x1
23.8(d)cm x 63.8(h)cm




4 Support x 2
13.6(w)cm x 23.7(d)cm




5 Support x 2
13.6(w)cm x 23.7(d)cm




6 Front Rail x1
13.6(w)cm x 6(d)cm




7 Drawer Front x 4
13.2(w)cm x 12.5(h)cm



8 Drawer Side x 8
21.7(w)cm x 12.5(h)cm



9 Drawer Bottom x 4
20.6(w)cm x 12.2(d)cm











10 Drawer Back x 4
11.5(w)cm x 12.5(h)cm




Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


<p>A </p> <p>Male Camlock x 12</p>	<p>B </p> <p>Female Camlock x 12</p>	<p>C </p> <p>Wooden Dowel x 14</p>
<p>D </p> <p>30 mm Screw x 32</p>	<p>E </p> <p>16 mm Screw x 4</p>	<p>F </p> <p>Handle x 4</p>
<p>G </p> <p>Handle x 4</p>	<p>H </p> <p>Protective Feet x 4</p>	

Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks

Step 1


Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 3

Push the male camlock into the entry hole.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.



Assembly Instructions

Step 1

To assemble the drawers


1. Screw drawer front **7** to 2 x drawer sides **8** using 4 x screw **D** as shown using a Phillips Screwdriver.

2. Slide drawer bottom **9** along grooves in 2 x panels **8**.

3. Connect drawer back **10** to 2 x drawer sides **8** with 4 x screws **D** using a Phillips Screwdriver

4. Connect either option of handle Either **F** or **G** to drawer front **7** with 1 x screw **E** with a Phillips Screwdriver.

5. Repeat steps above to complete 4 x drawers.




Step 2

1. Insert 4 x Male camlocks **A** into right side panel **3** as shown.

2. Insert 4 x Male camlocks **A** into left side panel **2** as shown.

3. Insert 4 x Male camlocks **A** and 2 x wooden dowel **C** into Top panel **1** as shown.




Assembly Instructions

Step 3

1. Connect 2 x supports **4** to left side panel **2** by locating them onto 2 x male camlocks.

2. Insert 4 x female camlocks **B** into the under side of supports **4** as shown.

Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.




Step 4

1. Insert 2 x Dowels **C** into the end of Front rail **6** as shown.

2. Insert 4 x Dowels **C** into the sides of 2 x Supports **5** as shown.

3. Locate Front Rail **6** and 2 x supports **5** onto Left side panel **2** as shown.



Step 5


1. Insert 2 x Dowels **C** into the end of Front rail **6** as shown.

2. Insert 4 x Dowels **C** into the sides of 2 x Supports **5** as shown.

3. Locate 4 x Male Camlocks in right side panel **3** into adjacent holes in 2 x supports **4** as shown.

4. Insert 4 x female camlocks **B** into the underside 2 x support **4** as shown.

Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.




Assembly Instructions

Step 6

1. Locate top panel **1** onto left side panel **2** and right side panel **3** as shown.

2. Insert 4 x female camlocks **B** into side panels **2** and **3**.


Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.



Step 7

1. Insert drawers into the unit.

2. Add 4 x Protective Feet **H**





Assembly Complete


Additional Components

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

 Washer x 2	 35mm Screw x 1	 Safety strap x 1	 wall plug x 1	 Screw x 1
---	---	---	--	--

Tools required



Drill
(for wall drilling only)

Supplementary Assembly Instructions

Step 1

The unit is floor standing, but it is recommended that the unit is secured to the wall.

1. Connect 1 x wall strap **K** to the units with 1 x washer **I** and 1 x screw **M** in position Shown

2. Move the units into desired position.

3. Mark the wall with a suitable scribe the position of the fixing hole.




Warning:
Before drilling, check wall for hidden pipes and cables.

4. Drill hole and insert wall plug **L**

5. Secure the strap to the wall using 1 x washer **I** and wall screw **J**

Note: To hide the strap behind the unit, drill the hole lower than the top of the unit.



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit**. **Consult a qualified tradesperson if you are unsure.**


Hints:

- 1: General rule:  always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.