


New England TallBoy

Assembly Instructions - please keep for future reference

QN911



Dimensions

Width - 30cm

Depth - 24cm

Height - 172cm

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

Components - Panels


Please check you have all the panels listed below




Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools required




Phillips screwdriver
(medium & large)

Using Camlocks

Step 1


Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 3

Push the male camlock into the entry hole.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.





Assembly Instructions

Step 1

1. Insert 4 x Dowels **A** into the bottom edge of upper left panel **2** and upper right panel **3**.

2. Connect panels **2** and **3** to Middle Panel **9** as shown using 4 x Screw **J**



Step 2


1. Insert 4 x Dowels **A** into the top edge of panels **2** and **3**.

2. Connect Top Panel **1** to panels **2** and **3** using 4 x Screw **J**

Step 3

1. Into Lower left panel **4** insert 2 x Male Camlocks **B** and 4 x Dowels **A** as shown.


2. Repeat for Lower right panel **5**



Step 4

1. Connect Panels **10** and **13** to panels **4** and **5** as shown.


2. Insert 4 x Female camlocks **C** and tighten



Assembly Instructions


Step 5

1. Into the underside of Middle panel **9** insert 4 x Male Camlocks **B** and 4 x Dowels **A**.




Step 6

1. Insert 2 x Hinge Pins **D** into the Top and Bottom of Door **6**
2. Locate the lower hinge into hole in Base panel **10**
3. Locate the upper section onto the lower section as shown.
4. Insert 4 x female camlocks **C** and tighten with a Phillips Screwdriver



Step 7

1. On the reverse of the unit connect Upper back panel **7** and lower back panel **8** as shown using 26 x Screw **M**



Assembly Instructions

Step 8


1. Into the Upper section insert 8 x Shelf Supports **I**

2. Into the Lower section insert 8 x Shelf Supports **I**

3. Into the underside of Middle panel **9** connect Magnetic Catch **K** using 2 x Screw **L**

4. To Door **6** Connect Catch Plate **F** using 2 x Screw **E**


5. Connect your choice of handle, either handle **G** or **Q** with Screw **H** as shown



Step 9

1. Insert 2 x Shelves **11** and 2 x Shelves **12** as shown.

2. Add 4 x Protective Feet **P**



Assembly Instructions

Step 10

This unit is floor standing but we recommend

1. On the reverse of the unit, in position shown, fix 1 x Wall Straps **N** using 1 x Screws **L**

2. Move the unit into desired position.



Warning:

The unit is heavy.

Lift with care.

3. Mark the wall with a suitable scribe the position of the fixing holes.




Warning:

Before drilling, check wall for hidden pipes and cables.

4. Drill hole and insert 1 x wall plug **O**

5. Connect to the wall using 1 x screw **O** as shown

Assembly Complete



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit**. **Consult a qualified tradesperson if you are unsure.**


Hints:

- 1: General rule:  always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.