
3 + 2 Drawer Chest

Assembly Instructions - Please keep for future reference

002 xx 8582



Dimensions

Width - 66.8cm

Depth - 33.0cm

Height - 75.2cm



Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 01709 534123** Please turn to back page for important information when contacting Customer Helpline.



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and seperate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws.

as this could damage the unit. Only use hand screwdrivers.

- Do Not dispose of packaging until assembly complete.
- Dispose of all packaging carefully and responsibly when assembly complete.

Care and maintenance


- To protect the furniture, position the furniture out of direct sunlight and away from direct heat sources such as radiators and fires.
- Do not place the furniture in excessively dry and humid conditions.
- From time to time check that there are no loose screws on this unit.
- Always lift furniture when moving it (do not drag) otherwise the joints may be damaged.


- Do not place hot or cold objects on the surface, always use protective mats to avoid marking the furniture.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.
- Clean spills up immediately
- Dust surfaces with a soft, dry, lint free cloth.

- More stubborn marks can be removed using a damp (not wet) cloth. Wipe the surface dry immediately using a soft lint free cloth.
- Do not use detergents, abrasive cleaning products or cleaning products that contain ammonia, solvents or silicone as these may damage the surface finish.

Components - Panels

Please check you have all the panels listed below





|0268| Bottom(63.4x32.7cm)



8553 Plinth (63.4x7.6cm)




9393

Draw Front (Top Right) (31.3x15.7cm)



9392


Draw Front (Top Left) (31.3x15.7cm)



0269 Left End Panel (73.7x32.8m)



0270 (73.7x32.8cm)



0271

9388


Drawer Front x3

(63.0x15.7cm)


Divider Panel (31.1x16.0cm)

indicate finished edges

Right End Panel



7065 Backpanel (67.0x66.0cm)



Drawer back x3 (60.1x10.0cm)



624xx7003

Drawer back x2 (27.6x10.0cm)



623xx7002

Right drawer side x5 (30.0x10.0cm)



622xx7002

Left drawer side x5 (30.0x10.0cm)



5671

Drawer Bottom x 3 (61.2x29.8cm)



4883

Drawer Bottom x 2 (28.7x29.8cm)



Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 01709 534123** Please turn to back page for important information when contacting Customer Helpline.

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly, In some case more fittings may be supplied than are required.

A	Large cam x 14 Code 760001103	B	Metal dowel x 24 Code 760003004	Θ	Small cam x 10 Code 760003005
Ð	Panel pin x 26 Code 760001012		8mm screw x 20 Code 700003510	3	Panel pin guide x 1 Code 684004501
G	18mm bolt x 10 Code 700002021	0	Runner x 10 Code 760001040	0	Handle x 5 Code 643003506
0	9mm bolt x 10 Code 690001078	®	L Bracket x1 Code 760001901	•	Screw x 2 Code 690001099

Tools required



Cross headed screwdriver (medium & large)



Tape Measure




Eye protection (when using a hammer)



Small Hammer

Ruler - Use this ruler to help correctly identify the screws 0 mm 10

Exploded View



Step 1

Fitting dowels to top panel.

Insert 6 metal dowels **B** into the top panel **9192**

Note: Tighten metal dowels up fully against the panel.

Do not over-tighten.

Step 2

Fitting cams to the bottom and plinth.


Insert 4 cams **A** into the plinth **8553** and bottom panel **0268**

Step 3

Fitting cams and dowels to the end panels.

a: Insert 2 metal cams A and 4 metal dowels B into left end panel [0269].


b: Insert 2 metal cams A and 4 metal dowels B into right end panel 0270.




Step 4

Attaching runners to the end panels.

Position the runner so that the second hole from the front of the runner lines up with the pre-drilled hole nearest to the edge of the panel. Use screws (a) to secure the runner.



Slide the runner forward revealing the back of the runner. The second hole to the back of the runner will now line up with the second pre-drilled hole.




Step 5


Fitting cams and runners to the divider.

Insert the runner $m{H}$ and 2 cams $m{A}$ into the left face of the divider panel $m{0271}$.

Turn the panel over and insert runner **(H)**.

Take care not to damage the floor when turning panel with exposed fittings over.






Step 6

Fitting dowels to drawer fronts.

Insert 2 metal dowels **B** into the the drawer fronts **9388**, **9392** and **9393**


Repeat on the remaining large drawer fronts **9388**.



Step 7

A: Insert small cams into left 622xx7002 and right 623xx7002 drawer sides.

Note: Ensure cam arrow points towards the edge with hole.




B: Insert wooden dowels in drawer back
[624xx7010] into holes in left [622xx7002] right [623xx7002] hand

Insert wooden dowels in drawer back

[624xx7003] into holes in left [622xx7002] right [623xx7002] hand drawer sides.

drawer sides.



C: Sit drawer bottom into groove on drawer front.


Ensure foil on the drawer bottom is facing upwards.

D: Locate grooves in left and right drawer sides around drawer bottom and slide down locating cams already inserted in left and right drawer sides onto dowels in drawer front.

Turn cams 180 degrees to lock.

E: Fit 2 bolts G through the pre-drilled hole in the drawer front 9388 and connect to the handle 1.

Repeat on the remaining drawers 9388, 9392 and 9393.



Step 8

Connect the top panel to the divider panel.

Connect the dowels in the top panel 9192 to the cams in the divider panel 0271.

Turn cams 180 degrees to lock.



Connect the left end panel to the bottom and plinth panels.


Connect the metal dowels in the left end 0269 panel to the cams in the bottom 0268 and plinth panels 8553.

Turn cams 180 degrees to lock.

Step 10

Connect the right end panel to the bottom and plinth panels.

Connect the metal dowels in the right end [0270] panel to the cams in the bottom [0268] and plinth panels [8553].




Step 11

Connect the end panels to the top.

Connect the dowels in the top panel **9192** to the cams in the right end panel **0270**, the left end panel **0269**.

Turn cams 180 degrees to lock.



Step 12

Squaring up the unit.


IMPORTANT!




Ensure a tape measure is used to square unit up.

Before securing the back it is necessary to square up the unit.

You can do this by measuring between XX - XX and YY - YY ensuring these are the same (DIAG 1). If they are not (DIAG 2) Apply slight pressure as indicated (DIAG 3) until they are the same.






Step 13

Attach the back panel to the unit.

Use the panel pin guide when locating the panel pins. This will hold the panel pins vertical and ensure the correct distance from the edge.




2nd Hole

Step 14

Fit the drawers.


Stand the unit up.

For this step we recommend you follow the helpful hints on the next page.



Step 15

Fit the drawer helpful hints.



- LINE UP THE FRONT HOLE IN THE DRAWER SIDE WITH THE 2ND THREADED HOLE IN THE RUNNER.
- WHILE PUSHING THE RUNNER AGAINST THE DRAWER SIDE, SCREW THE BOLT FROM THE **INSIDE** OF THE DRAWER, THROUGH THE HOLE IN THE DRAWER SIDE AND INTO THREADED HOLE IN THE RUNNER.
- REPEAT ON OPPOSITE DRAWER SIDE

Step 16

Fixing to wall

We recommend that this unit is fixed to a suitable wall to prevent possible overbalancing. We have included a fixing bracket for this. No fixing screws are provided as they will need to suit the wall type, and the length of screw will depend on the distance from the back of the unit to the wall. Please ensure fixings used are appropriate to your wall type. Locate the bracket to the top panel or to the end panel as close to top as possible. We do not specify exact location for the bracket, this is left to the customer's discretion.

With help move the unit into position.



Warning: 2 people to lift. Lift with care.



Warning:

Please take care when drilling into the wall, avoiding any pipes and wires. Wear safety goggles when drilling. The use of residual current device (RCD) is recommended when working with tools. If in doubt consult a qualified person.









WARNING


IN ORDER TO PREVENT OVERTURNING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICE PROVIDED

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over:


- Use the wall attachment device provided.
- Never allow children to climb or hang on drawers, doors or shelves.
- Place heaviest items in the lower drawers or shelves.
- Unless specifically designed to accomodate, do not set TV's or other heavy objects on top of this product.
- Never open more than one drawer at a time.

An attachment device is provided with your product. However you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified trades person.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



Congratulations! Your unit is complete.



Important Information

If you need help or have damaged or missing parts, call the Customer Helpline:

01709 534123 8am - 4.30pm (Monday to Thursday) 8am - 2.30pm (Fridays)

(by contacting the customer service line your statutory rights are not affected)

Please have the following information to hand:

- >> Unit Description
- >> Product Code
- >> Product Colour
- >> Place of Purchase
- >> Catalogue Ref. No.
- >> Item Code
- >> Assembly Instructions

We do have an answer machine should you contact us out of office hours, so in addition to the above information could you leave your name, address, daytime telephone number and the nature of your call on the answerphone. All calls will be actioned asap.

You can also e-mail your requests to us at:

customer.helpdesk@addspacefl.co.uk

Alternatively, you can write to us at: Customer Service Department, Addspace Furniture Limited, Braithwell Way, Hellaby Industrial Estate, Hellaby, Rotherham, South Yorkshire, S66 8QY.

Notes;